

anti-limescale magnoball™



- Helps with limescale removal over time*
- Cost effective & long-term maintenance for washing machines & dishwashers.
- Non-toxic & septic tank safe solution.
- Latex free materials & Allergy UK approved.

How to use

Washing Machines:

Place the Magnoball™ into the drum of your machine in every cycle, along with your laundry & usual detergents.

Dishwashers:

Place the Magnoball™ into the cutlery holder or on a shelf in every cycle, along with all dishware & your usual detergents.



More about our Magnoball"

Ecozone's Magnoball™ is a maintenance product for your washing machine & dishwasher, that can help to show the effects of limescale removal in the wash process after around five washes. An excellent long-term solution that can be used in every cycle below 60°c degrees.

Check out our credentials







*after around 5 wash cycles.

EN Materials: Magnets and TPE (Thermoplastic Elastomer). For a full list of Ingredients, go to ecozone.com.

Medical Personnel can request the data sheet via +31 36 54 94 777

EN The Magnobali™ contains a powerful magnet. Keep away from pacemakers, electronic data carriers, VCR's, DVD's, TV's and computers. The Magnoball™ has been tested safe for use in washing machines and dishwashers. Do not use in a tumble dyer or on drying cycles. Do not use at temperatures above 60°c. Keep out of reach of children and animals. The Magnoball™ is not a toy. Ecozone does not accept any liability for misuse of this product.




For more information www.ecozone.com
@ecozoneuk
@ecozoneproducts

UK address:
HG Hagesan (UK) Ltd,
Weston Business Centre,
Parsonage Road,
Takeley, Essex, CM22 6PU
Tel: +44 (0) 1206 822 744

Tel: +31 36 54 94 700

Please recycle packaging & check local recyling EU address:



M807