



ecozone[®]

Since 2000

BIOActive

fabric softener & restorer

How to use

Pour the product in the washing machine dispenser drawer. Use in every cycle.

Dosing instructions

2-3 kg	soft/medium water	18 ml
4-6 kg	soft/medium water	27 ml
2-3 kg	hard water	27 ml
4-6 kg	hard water	40 ml

For further softness & fragrance add ½ cap more

More about this product

- ✓ Restores colours and fibres
- ✓ With enzyme action
- ✓ Makes ironing easier



Recycle with the cap on.

Ingredients 5-15 % cationic surfactants, < 5 % enzymes, preservative (Lactic Acid), Perfume, Magnesium chloride, isopropyl alcohol. Also : Water.

This product is not intended for large-scale cleaning. 95 % of the total ingredients are from natural origin.

P101 - If medical advice is needed, have product container or label at hand. **P102** - Keep out of reach of children.

UK address:

HG Hogeslan (UK) Ltd,
Weston Business Centre, Parsonage Road,
Tolsey, Essex, CM22 6PU
Tel: +44 (0) 1206 822 744

EU address:

HG International b.v.
P.J. Oudeweg 41,
1314 CJ Almere,
The Netherlands
Tel: +31 36 54 94 700

For more information

www.ecozone.com [@ecozoneuk](https://www.facebook.com/ecozoneuk) [@ecozoneproducts](https://www.instagram.com/ecozoneproducts)

Art: 2003100106

11e

5 060101 534861 >