

ecozone®
Since 2000

laundry stain remover

- ✓ Enzymatic pre-wash stain remover for most fabrics.
- ✓ Tackles stubborn stains such as tomato, chocolate, blood and more without bleach.
- ✓ Easy direct applicator with nozzle to target stains.
- ✓ Made with plant-based & biodegradable ingredients*

How to use

1. Check the washing instructions on your clothes.
2. Apply the stain remover to the stain & rub it with the handy brush nozzle.
3. Leave the stain remover to sit for 10 minutes.
4. Place soiled item into washing machine.

EN Ingredients: 5-15% Anionic Surfactants, <5% Non ionic Surfactants, <5% Phosphonate, Phenoxyethanol, Enzymes. Also contains Alcohols, C12-14 (even numbered), Ethoxylated <2.5 EO, Sulfates, Sodium Salts; Alcohols, C13-15, Branched and Linear, Ethoxylated (7 EO). **For a full list of ingredients, go to ecozone.com**

EN Test in an inconspicuous area before using.

**Medical Personnel can request the data sheet via
+31 36 54 94 777**



DANGER

EN DANGER. Causes serious eye damage. Keep out of reach of children. **IF ON SKIN:** Wash with plenty of water. **IF IN EYES:** Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical advice/attention. If skin irritation occurs: Get medical advice/attention. Dispose content/package according to local legislative.

UFI: HJ2K-G3WR-D00E-17MN

EU ECOLABEL: EE/006/00001



STAIN

250ml e